Digital Video Recorder

Quick Start Guide

TABLE OF CONTENTS

| Chapter 1 | Description of Panels |
|-----------|----------------------------------|
| 1.1 | Front Panel |
| 1.2 | Rear Panel7 |
| Chapter 2 | Installation and Connections9 |
| 2.1 | DVR Installation |
| 2.2 | Hard Disk Installation9 |
| 2.3 | RS-485 and Controller Connection |
| 2.4 | HDD Storage Calculation Chart |
| Chapter 3 | Menu Operation |
| 3.1 | Menu Structure |
| 3.2 | Startup and Shutdown |
| 3.3 | Activating Your Device |
| 3.4 | Login and Logout |
| τ | User Login15 |
| τ | User Logout16 |
| 3.5 | Configuring the Signal Input |
| 3.6 | Using the Setup Wizard |
| 3.7 | Network Settings |
| 3.8 | Adding IP Cameras |
| 3.9 | Live View |
| 3.10 | Recording Settings |
| 3.11 | Playback |
| Chapter 4 | Accessing by Web Browser |

Quick Start Guide

This Manual is applicable to TVI HD Digital Video Recorder (DVR).

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version in the company website

Please use this user manual under the guidance of professionals.

Legal Disclaimer

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. OUR COMPANY SHALL NOT TAKE ANY RESPONSIBILITES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, OUR COMPANY WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. OUR COMPANY SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Regulatory Information

FCC Information

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Conditions

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement



This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, the LVD Directive 2014/35/EU, the RoHS Directive 2011/65/EU.



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection

points. For more information see: www.recyclethis.info



2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate

cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info

Industry Canada ICES-003 Compliance

This device meets the CAN ICES-3 (A)/NMB-3(A) standards requirements.

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss. The precaution measure is divided into "Warnings" and "Cautions"

Warnings: Serious injury or death may occur if any of the warnings are neglected.

Cautions: Injury or equipment damage may occur if any of the cautions are neglected.

| Warnings Follow | these | Cautions Follow these precautions | | |
|--------------------------|--------|-----------------------------------|--|--|
| safeguards to prevent se | erious | to prevent potential injury or | | |
| injury or death. | | material damage. | | |



Warnings

- Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Please refer to technical specifications for detailed information.
- Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100~240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical specifications for detailed information.
- Do not connect several devices to one power adapter as adapter overload may cause over-heating or a fire hazard.
- Please make sure that the plug is firmly connected to the power socket.
- If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

Preventive and Cautionary Tips

Before connecting and operating your device, please be advised of the following tips:

- Ensure unit is installed in a well-ventilated, dust-free environment.
- Unit is designed for indoor use only.
- Keep all liquids away from the device.
- Ensure environmental conditions meet factory specifications.
- Ensure unit is properly secured to a rack or shelf. Major shocks or jolts to the unit as a result of dropping it may cause damage to the sensitive electronics within the unit.
- Use the device in conjunction with an UPS if possible.
- Power down the unit before connecting and disconnecting accessories and peripherals.
- A factory recommended HDD should be used for this device.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.

Applicable Models

This manual is applicable to the TVI DVR series.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

| Symbol | Description |
|--------|---|
| | Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results. |
| NOTE | Provides additional information to emphasize or supplement important points of the main text. |

Chapter 1 Description of Panels

1.1 Front Panel




Figure 1. 1 Front Panel 2

| No. | I | Name | Function Description |
|-----|-----------|-----------------------------------|--|
| | POWER | | Turns yellow when the device s running. |
| 1 | STATUS | | Flickers red when data is being read from or written to HDD, and turns yellow when the SHIFT function is realized. |
| | Tx/Rx | | Flickers yellow when network connection is functioning properly. |
| | | SHIFT | Switches between the numeric or letter input and functions of the composite keys. |
| | | 1/MENU | Enters numeral "1"; Accesses the main menu interface. |
| | | | Enters numeral "2"; |
| | | | Enters letters "ABC"; |
| | | | Uses the F1 button to select all items in a list field; |
| | Composite | 2/ABC/F1 3/DEF/F2 4/GHI/ESC | Turns on/off PTZ light in PTZ Control mode, and use it to zoom |
| | | | out the image; |
| | | | Switches between main and spot video output in live view or |
| | | | playback mode. |
| 2 | | | Enters numeral "3"; |
| - | Keys | | Enters letters "DEF"; |
| | | | Uses the F2 button to change the tab pages; |
| | | | Zooms in the image in PTZ control mode. |
| | | | Enters numeral "4"; |
| | | | Enters letters "GHI"; Exits and back to the previous menu. |
| | | | Exits and back to the previous menu. |
| | | | Enters letters "JKL"; |
| | | 5/JKL/EDIT | Deletes characters before cursor; |
| | | | Checks the checkbox and select the ON/OFF switch; |
| | | | Starts/stops record clipping in playback. |
| | | 6/MNO/PLAY | Enters numeral "6"; |

Table 1. 1 Description of Front Panel 2

| No. | Name Function Description | |
|-----|---------------------------|---|
| | | Enters letters "MNO"; |
| | | Accesses to playback interface in Playback mode. |
| | | Enters numeral "7"; |
| | | Enters letters "PQRS"; |
| | 7/PQRS/REC | Accesses to manual record interface; |
| | | Manually enables/disables record. |
| | | Enters numeral "8"; |
| | 8/TUV/PTZ | Enters letters "TUV"; |
| | | Accesses PTZ control interface. |
| | | Enters numeral "9"; |
| | 9/WXYZ/PREV | Enters letters "WXYZ"; |
| | | Multi-channel display in live view. |
| | | Enters numeral "0"; |
| | 0/A | Shifts the input methods in the editing text field. (Upper and |
| | | lowercase, alphabet, symbols or numeric input). |
| | | Navigates between different fields and items in menus. |
| | | Uses the Up and Down buttons to speed up and slow down the |
| | | playing of video files in Playback mode. |
| | DIRECTION | The Left and Right button will select the next and previous |
| | | record files. |
| | | Cycles through channels in Live View mode. |
| 3 | | Controls the movement of the PTZ camera in PTZ control mode. |
| | | Confirms selection in any of the menu modes. |
| | | Checks the checkbox. |
| | ENTER | Plays or pauses the playing of video files in Playback mode. |
| | | Advances the video by a single frame in single-frame Playback |
| | | mode. |
| | | Stops/starts auto switch in Auto-switch mode. |
| 4 | | Universal Serial Bus (USB) ports for additional devices such as |
| 4 | USB Interface | USB mouse and USB Hard Disk Drive (HDD). |
| 5 | IR Receiver | Receiver for IR remote control. |

1.2 Rear Panel



The rear panel vaires according to different models. Please refer to the actual product. The following figure is for reference only.




Figure 1. 2 Rear Panel

| No. | Item | Description | |
|-----|-------------------|---|--|
| 1 | VIDEO IN | BNC interface for TVI and analog video input. | |
| 2 | AUDIO IN | RCA connector | |
| 3 | AUDIO OUT | RCA connector. | |
| 4 | VGA | DB15 connector for VGA output. Display local video output and | |
| 4 | | menu. | |
| 5 | HDMI | HDMI video output connector. | |
| 6 | USB | Universal Serial Bus (USB) ports for additional devices | |
| 7 | Network Interface | Connector for network | |
| 8 | RS-485 | Half-duplex connector for RS-485 devices. | |
| 9 | Power Supply | 12VDC power supply. | |
| 10 | Power Switch | Switch for turning on/off the device. | |
| 11 | GND | Ground (needs to be connected when NVR starts up). | |
| 12 | VIDEO OUT | BNC connector for video output. | |
| 13 | GND | ND Ground (needs to be connected when NVR starts up). | |
| 14 | | Connector for alarm input. | |
| | Alarm Interface | Connector for alarm output | |

Connector for alarm output.

Table 1. 2 Description of Front Panel

Chapter 2 Installation and Connections

2.1 DVR Installation

During the installation of the DVR:

- 1. Use brackets for rack mounting.
- 2. Ensure there is ample room for audio and video cables.
- 3. When installing cables, ensure that the bend radius of the cables are no less than five times than its diameter.
- 4. Connect both the alarm and RS-485 cable.
- 5. Allow at least $2 \text{cm} (\approx 0.75 \text{-inch})$ of space between racks mounted devices.
- 6. Ensure the DVR is grounded.
- 7. Environmental temperature should be within the range of -10 °C to 55 °C, 14 °F to 131 °F.
- 8. Environmental humidity should be within the range of 10% to 90%.

2.2 Hard Disk Installation

Before you start:

Before installing a hard disk drive (HDD), please make sure the power is disconnected from the DVR. A factory recommended HDD should be used for this installation.

One or two SATA hard disks can be installed depending on different models.

Tools Required: Screwdriver.



As the installation steps of HDD are similar among different models, here we take the steps of one model as the example.

Steps:

1. Remove the cover from the DVR by unfastening the screws on the back and side.





Figure 2. 1 Remove the Cover

2. Connect one end of the data cable to the motherboard of DVR and the other end to the HDD.




Figure 2. 2 Connect the Data Cable

3. Connect the power cable to the HDD.



Figure 2. 3 Connect the Power Cable

4. Place the HDD on the bottom of the device and then fasten the screws on the bottom to fix the HDD.




Figure 2. 4 Install the HDD

5. Re-install the cover of the DVR and fasten screws.

2.3 RS-485 and Controller Connection

Typical Connection :



To connect PTZ to the DVR:

- 1. Disconnect *pluggable block* from the RS-485 terminal block.
- 2. Press and hold the orange part of the *pluggable block*; insert signal cables into slots and release the orange part. Ensure signal cables are in tight.
- 3. Connect A+ on PTZ to D+ on terminal block and B- on controller to D- on terminal block. Fasten stop screws.
- 4. Connect *pluggable block* back into terminal block.



Make sure both the controller and DVR are grounded.

2.4 HDD Storage Calculation Chart

The following chart shows an estimation of storage space used based on recording at one channel for an hour at a fixed bit rate.

| Bit Rate | Storage Used |
|----------|--------------|
| 96K | 42M |
| 128K | 56M |
| 160K | 70M |
| 192K | 84M |
| 224K | 98M |
| 256K | 112M |
| 320K | 140M |
| 384K | 168M |
| 448K | 196M |
| 512K | 225M |
| 640K | 281M |
| 768K | 337M |
| 896K | 393M |
| 1024K | 450M |
| 1280K | 562M |
| 1536K | 675M |
| 1792K | 787M |
| 2048K | 900M |
| 4096K | 1.76G |
| 8192K | 3.52G |
| 16384K | 7.03G |




Please note that supplied values for storage space used are just for reference. Storage space used is estimated by formulas and may have some deviation from actual value.

Chapter 3 Menu Operation

3.1 Menu Structure



The menu structure varies according to different models.





3.2 Startup and Shutdown

Proper startup and shutdown procedures are crucial to expanding the life of the DVR. To start your DVR:

- Check the power supply is plugged into an electrical outlet. It is HIGHLY recommended that an Uninterruptible Power Supply (UPS) be used in conjunction with the device. The Power button) on the front panel should be red, indicating the device is receiving the power.
- 2. Press the POWER button on the front panel. The Power LED should turn blue. The unit will begin to start.

After the device starts up, the wizard will guide you through the initial settings, including modifying password, date and time settings, network settings, HDD initializing, and recording.

To shut down the DVR:

1. Enter the Shutdown menu.

Menu > Shutdown



Figure 3. 2 Shutdown

- 2. Select the Shutdown button.
- 3. Click the Yes button.

3.3 Activating Your Device

Purpose:

For the first-time access, you need to activate the device by setting an admin password. No operation is allowed before activation. You can also activate the device via Web Browser, SADP or client software.

Steps:

1. Input the same password in the text field of Create New Password and Confirm New Password.




Figure 3. 3 Set Admin Password

STRONG PASSWORD RECOMMENDED– We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

2. Click OK to save the password and activate the device.



For the old version device, if you upgrade it to the new version, the following dialog box will pop up once the device starts up. You can click **YES** and follow the wizard to set a strong password.



Figure 3. 4 Warning of Weak Password

3.4 Login and Logout

User Login

Purpose:

You have to log in to the device before operating the menu and other functions. *Steps:*

1. Select the User Name in the dropdown list.



Figure 3. 5 Login

- 2. Input Password.
- 3. Click **OK** to log in.



In the Login interface, for the admin, if you have entered the wrong password for 7 times, the account will be locked for 60 seconds. For the operator, if you have entered the wrong password for 5 times, the account will be locked for 60 seconds.

| Login | | | | | |
|--|-----------|--|--|--|--|
| User Name | admin ~ | | | | |
| Password | | | | | |
| | Attention | | | | |
| Incorrect password. You still have 6 chances. Please try again. | | | | | |
| | | | | | |
| | OK Cancel | | | | |

Figure 3. 6 User Account Protection for the Admin

| | Login | | |
|-----------|---|---|--|
| User Name | 01 | | |
| Password | | | |
| | Attention | | |
| | orrect password. You still have 4 chances. ease try again. | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | OK Cance | I | |

Figure 3.7 User Account Protection for the Operator

User Logout

Purpose:

After logging out, the monitor turns to the live view mode and if you want to perform any operations, you need to enter user name and password log in again.

Steps:

1. Enter the Shutdown menu.

Menu > Shutdown



Figure 3. 8 Logout

2. Click Logout.



After you have logged out the system, menu operation on the screen is invalid. It is required to input a user name and password to unlock the system.

3.5 Configuring the Signal Input

After the startup and login, the device system enters the Wizard for configuring the signal input. *Steps:*

- 1. Check the checkbox to select different signal input types: TVI/CVBS, AHD, and IP.
- 2. Click **Apply** to save the settings.

| Wizard | | | | | |
|---------------------------------|----------------|-------------------|------|------|--|
| | Sig | gnal Input Status | | | |
| Camera | TVI/CVBS | AHD | | IP | |
| A1 | ✓ | | | | |
| A2 | <u> </u> | | | | |
| A3 | ✓ ✓ | | | | |
| A4 A5 | ¥ | | | | |
| A6 | | | | | |
| A7 | ~ | | | | |
| A8 | ✓ | | | | |
| A9 | <u> </u> | | | | |
| A10 A11 | | | | | |
| A11 | ¥ | | | | |
| A13 | | | | | |
| A14 | v | | | | |
| A15 | ✓ | | | | |
| A12 A13 A14 A15 A16 | Z | | | | |
| | ieras Access 2 | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | pply | Exit | |

Figure 3.9 Configure Signal Input Type



You can also click Menu > Camera > Signal Input Status to configure the signal input.

Steps:

1. Enter the Signal Input Status interface.

Menu > Camera > Signal Input Status

2. Check the checkbox to select different signal input types: TVI/CVBS, AHD or IP (For E series DVR, there is no signal input configuration interface.).

| Camera | | /BS | AHD | IP | |
|---------------|------------------|----------------|-------------------------------|---------------------|--------------|
| A1 | ⊻ | | | | |
| A2 | <u> </u> | | | | |
| A3 | <u> </u> | | | | |
| A4 | ✓ | | | | |
| A5 | ✓ | | | | |
| A6 | ~ | | | | |
| A7 | ✓ | | | | |
| A8 | ✓ | | | | |
| A9 | ✓ | | | | |
| A10 | ✓ | | | | |
| A11 | ~ | | | | |
| A12 | ~ | | | | |
| A13 | ~ | | | | |
| A14 | ~ | | | | |
| A15 | ~ | | | | |
| A16 | ~ | | | | |
| | | | | | |
| Max. IP Camei | ras Access | 2 | | | |
| aab hua vidaa | abannala ara ara | upod in ooduon | ce, e.g., CH01 and CH02, CH03 | and CH04 and the tr | o channols i |

Figure 3. 10 Configure Signal Input Type

3. Click Apply to save the settings.

NOTE

- For this series DVR, each two video channels are grouped in sequence, e.g., CH01 and CH02, CH03 and CH04..., and each two channels in the same group must be connected with the same type of video source selected on GUI. For example, when the TVI/CVBS signal mode is selected, then either TVI or CVBS signal input can be connected to the channels in the same group; and when the AHD signal mode is selected, only the AHD signal input can be connected.
- The default TVI/CVBS signal input type also supports the auto detection of 3MP signal. Each two types of the signals can be mixed randomly.
- In the live view interface, when there is no video signal of the analog channel, the corresponding connectable video signal type message can be displayed on the screen.
- The IP channels will not be displayed on the interface and you can view the max. IP camera accessible number in the Max. IP Camera Access text field.

3.6 Using the Setup Wizard

The Setup Wizard can walk you through some important settings of the device. By default, the Setup Wizard starts once the device has loaded.

Check the checkbox to enable Setup Wizard when device starts. Click **Next** to continue the setup wizard. Follow the guide of the Setup Wizard to configure the system resolution, system date/time, network settings, HDD management, record settings, etc.

| | Wizard | |
|-------------|------------------------------|-------------|
| Time Zone | (GMT+08:00) Beijing, Urumqi, | Singapore ~ |
| Date Format | MM-DD-YYYY | |
| System Date | 04-23-2015 | - |
| System Time | 20:30:39 | ۰ |
| | | |
| | Previous | ext Exit |

Figure 3. 11 Wizard

3.7 Network Settings

Purpose:

Network settings must be properly configured before you operate DVR over network.

Steps:

- 1. Enter the Network Settings interface.
 - Menu > Configuration > Network

| NIC Туре | | 10M/100M Self-adaptive | | | | |
|----------------------|-------------|--|------------|--|--|--|
| Enable DHCF | > | | | | | |
| IPv4 Addre | 10 .16 .1 | .102 IPv6 Addre fe80::8ee7:48ff:fe73:e | | | | |
| IPv4 Subn | 255.255.255 | | IPv6 Addre | | | |
| IPv4 Defa | 10 .16 .1 | .254 | IPv6 Defa | | | |
| MAC Address | 5 | 8c:e7:48:73:ea | :1f | | | |
| MTU(Bytes) | | 1500 | | | | |
| Preferred DNS Server | | 10.1.7.88 | | | | |
| Alternate DNS Server | | 10.1.7.77 | | | | |

Figure 3. 12 Network Settings



1 self-adaptive 10M/100M/1000M network interface or 1 self-adaptive 10M/100M bps network interface provided for other models.

- 2. Select the General tab.
- **3.** In the **General Settings** interface, you can configure the following settings: NIC Type, IPv4 Address, IPv4 Gateway, MTU and DNS Server.

If the DHCP server is available, you can check the checkbox of **DHCP** to automatically obtain an IP address and other network settings from that server.

4. After having configured the general settings, click the Apply button to save the settings.

3.8 Adding IP Cameras

Purpose:

Before you can get live video or record the video files, you should add the network cameras to the connection list of the device.

Before you start:

Ensure the network connection is valid and correct, and the IP camera to add has already been activated. Please refer to the *User Manual* for activating the inactive IP camera.

You can select one of the following three options to add the IP camera.

• OPTION 1:

Steps:

1. Select the Add IP Camera option from the right-click menu in live view mode or click Menu> Camera> Camera to enter the IP camera management interface.

| C | am | Add/De | . Stat | tus | Security | IP Came | ra Addr | Edit | | Upgrade | Camera Nam |
|----|--------|------------|--------|---------|----------|----------|---------|------|--------|---------|-------------|
| | | ۲ | | | Active | 192.168 | .1.64 | | | | |
| | | \odot | - | | Active | 10.16.1. | 14 | | | - | <u></u> |
| | | ٢ | | | Active | 10.16.1 | 205 | | | - | — |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| < | | | 1 | | | | | | | | > |
| | Refre | sh O | ne-to | uch A | Upg | rade | Delete | C | One-to | ouch A | Custom Addi |
| Ne | t Rece | ive Idle B | andwi | idth: 1 | 28Mbps | | | | | | |
| | | | | | Loinspo | | | | | | |
| | | | | | | | | | | | Exit |

Figure 3. 13 IP Camera Management

2. Select the IP camera from the list and click the same admin password of the DVR's).

• OPTION 2:

Steps:

1. Click the Custom Adding button to pop up the Add IP Camera (Custom) interface.

| | | Add IP Can | nera (Custor | 1) | |
|--------|--------------|------------|--------------|--------------|------|
| No. | IP Address | Amount | of Channels | Device Model | P |
| 1 | 10.16.1.93 | 1 | | IP Dome | H |
| | | | | | |
| | | | | | |
| < | | | | | · |
| IP Car | mera Address | 10.16.1.93 | | | |
| Protoc | ol | | | | - |
| Manag | gement Port | 8000 | | | |
| Trans | fer Protocol | Auto | | | |
| User N | Name | admin | | | |
| Admin | Password | | | | |
| ✓ Con | tinue to Add | | | | |
| | | Se | arch | Add | Back |

Figure 3. 14 Add IP Camera

- 2. Select the detected IP camera and click the Add button to add it directly, and you can click the Search button to refresh the online IP camera manually.
- **OPTION 3:** •

You can choose to custom add the IP camera by editing the parameters in the corresponding text field and then click the Add button to add it.

Live View 3.9

Some icons are provided on screen in Live View mode to indicate different camera status. These icons include:

Live View Icons

In the live view mode, there are icons at the right top of the screen for each channel, showing the status of the record and alarm in the channel, so that you can find problems as soon as possible.



Indicating that there is an alarm or are alarms. Alarm includes video loss, tampering, motion detection or sensor alarm, etc.

Recording (manual record, continuous record, motion detection or alarm triggered record)



Alarm & Recording

Event/Exception (event and exception information, appears at the lower-left corner of the screen.)

3.10 Recording Settings

Before you start:

Make sure that the disk has already been installed. If not, please install a disk and initialize it. You may refer to the user manual for detailed information.

Purpose:

Two kinds of record types are introduced in the following section, including Instant Record and All-day Record.

And for other record types, you may refer to the user manual for detailed information.



After rebooting all the manual records enabled are canceled.

Steps:

1. On the live view window, right lick the window and move the cursor to the **Start Recording** option, and select **Continuous Record** or **Motion Detection Record** on your demand.




Figure 3. 15 Start Recording from Right-Click Menu

2. Click the **Yes** button in the pop-up Attention message box to confirm the settings. All the channels will start to record in the selected mode.

3.11 Playback

The recorded video files on the hard disk can be played back in the following modes: instant playback, all-day

playback for the specified channel, and playback by normal/event/smart/tag/sub-periods/external file search.

Steps:

1. Enter playback interface.

Click Menu>Playback or select Playback from the right-click menu

- 2. Check the checkbox of channel(s) in the channel list and then double-click to select a date on the calendar.
- 3. You can use the toolbar in the bottom part of Playback interface to control playing progress.



Figure 3. 16 Playback Interface

4. Select the channel(s) you want to play back by checking the checkbox(s), or execute simultaneous playback of multiple channels.

Chapter 4 Accessing by Web Browser

NOTE

You shall acknowledge that the use of the product with Internet access might be under network security risks. For avoidance of any network attacks and information leakage, please strengthen your own protection. If the product does not work properly, please contact with your dealer or the nearest service center.

Purpose:

You can get access to the device via web browser. You may use one of the following listed web browsers: Internet Explorer 6.0, Internet Explorer 7.0, Internet Explorer 8.0, Internet Explorer 9.0, Internet Explorer 10.0, Apple Safari, Mozilla Firefox, and Google Chrome. The supported resolutions include 1024*768 and above.

Steps:

- 1. Open web browser, input the IP address of the device and then press Enter.
- 2. Log in to the device.
 - If the device has not been activated, you need to activate the device first before login.

| Activation | | |
|------------|--|---------|
| User Name | admin | |
| Password | ••••• | Strong |
| | Valid password range [8-16]. You can use a combination of numbers, lowercase, uppercase and special character for your password with at least two kinds of them contained. | Curring |
| Confirm | ••••• | |
| | | ОК |

Figure 4.1 Set Admin Password

- 1) Set the password for the admin user account.
- 2) Click **OK** to log in to the device.

STRONG PASSWORD RECOMMENDED– We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

• If the device is already activated, enter the user name and password in the login interface, and click the **Login** button.

| 1 admin |
|---------|
| |
| |
| Login |
| |
| |

Figure 4. 2 Login

3. Install the plug-in before viewing the live video and managing the camera. Please follow the installation prompts to install the plug-in.

NOTE

You may have to close the web browser to finish the installation of the plug-in.

After login, you can perform the operation and configuration of the device, including the live view, playback, log search, configuration, etc.