

TURBO HD

TVI Bullet Camera

User Manual

are any questions, or requests, please do not hesitate to contact the dealer. Thank you for purchasing our product. If there

incorrect places or printing errors, and the this manual. We will readily improve or update content is subject to change without notice. the products or procedures described in the The updates will be added to the new version of This manual may contain several technical

camera parameters and functions. Please refer to the product specification for

Regulatory Information

FCC Information

a residential area is likely to cause harmful communications. Operation of this equipment in cause harmful interference to radio generates, uses, and can radiate radio a commercial environment. This equipment interference when the equipment is operated in digital device, pursuant to part 15 of the FCC required to correct the interference at his own interference in which case the user will be in accordance with the instruction manual, may frequency energy and, if not installed and used Rules. These limits are designed to provide tested and found to comply with the limits for a FCC compliance: This equipment has been reasonable protection against harmful

FCC Conditions

Rules. Operation is subject to the following two This device complies with part 15 of the FCC

- 1. This device may not cause harmful
- 2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement



supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized Europear This product and - if applicable - the

standards listed under the Low Voltage Directive the RoHS Directive 2011/65/EU. 2006/95/EC, the EMC Directive 2004/108/EC,



upon the purchase of equivalent new equipment, Union. For proper recycling, return Products marked with this symbol this product to your local supplier municipal waste in the European cannot be disposed of as unsorted 2012/19/EU (WEEE directive):

municipal waste in the European cannot be disposed of as unsorted 2006/66/EC (battery directive): This product contains a battery that

For more information see: www.recyclethis.info or dispose of it at designated collection points.

this symbol, which may include lettering to battery information. The battery is marked with more information see: www.recyclethis.info. supplier or to a designated collection point. For For proper recycling, return the battery to your indicate cadmium (Cd), lead (Pb), or mercury (Hg). See the product documentation for specific

1 Introduction


1.1 Product Features

sensor with high sensitivity and advanced circuit low image distortion and low noise, etc. , which design technology. It features high resolution, image processing system. makes it suitable for surveillance system and This series of camera adopts new generation


- High performance CMOS sensor and high
- Low illumination; resolution bring high-quality image;
- OSD menu, parameters are configurable;
- Support auto white balance, auto gain control, electronic shutter control;
- Support image effect adjustment;
- Unit transmission control;
- Advanced 3-axis design meets different installation requirements.

1.2 Overview


1.2.1 Overview of Type I Camera



1.2.2 Overview of Type | Camera



1.2.3 Overview of Type III Camera



2 Installation

Please make sure that the device in the package is in good condition and all the assembly parts are included.

- Make sure that all the related equipment is power-off during the installation
- Check the specification of the products for the installation environment.
- Check whether the power supply is matched with your power output to avoid damage.
- Please make sure the wall is strong enough to and the mounting. withstand three times the weight of the camera
- If the wall is the cement wall, you need to insert expansion screws before you install the camera If the wall is the wooden wall, you can use
- If the product does not function properly, please contact your dealer or the nearest service center. Do not disassemble the camera self-tapping screw to secure the camera. for repair or maintenance by yourself.

2.1 Ceiling Mounting for Type I Type II/Camera

- Drill the screw holes in the ceiling according to the supplied drill template.
- 2. Hammer the supplied plastic expansion bolt into the screw holes.



Figure 2-1 Drill Template

4. Fix the camera to the ceiling with the supplied 3. Route the cables to the cable hole and connect the corresponding power cable and video cable




Figure 2-2 Fix the Camera to the Ceiling

- 1).Loosen No.3 adjusting screw to adjust the 5.Adjust the surveillance angle. panning position (0°~360)
- 2). Tighten No.3 adjusting screw.
- 3).Loosen the No.2 adjusting screw to adjust the tilting position $(0^{\circ} \sim 90)$.
- 4).Tighten No.2 adjusting screw.
- 5).Loosen No. 1 adjusting screw to adjust the 6). Tighten No.1 adjusting screw. azimuth angle of the image $(0^{\circ} \sim 360)^{\circ}$.




Figure 2-3 3-axis Adjustment

2.2 Wall Mounting for Type III Camera

Steps:

- 2. Hammer the supplied plastic expansion bolt into 1.Drill the screw holes and the cable hole in the the screw holes. ceiling according to the supplied drill template.

Figure 2-4 Drill Template

4. Fix the camera to the ceiling with the supplied 3. Route the cables to the cable hole and connect the corresponding power cable and video cable




Figure 2-5 Fix the Camera to the Wall

- 5. Adjust the surveillance angle
- 1). Loosen No.3 adjusting screw to adjust the pan position($0^{\circ} \sim 360^{\circ}$).
- Tighten No.3 adjusting screw.
- 3). Loosen No.2 adjusting screw to adjust the tilting position($0^{\circ} \sim 90^{\circ}$).
- 4). Tighten No. 2 adjusting screw.
- 5). Loosen No.1 adjusting screw to adjust the rotation position(0° ~ 360°)
- 6). Tighten No. 1 adjusting screw




Figure 2-6 3-axis Adjustment

3 Menu Operation




Figure 3-1 Main Menu

A coaxial camera controller (purchase separately) camera parameters. is required to select the menu and adjust the

3.1 VIDEO.OUT

You can set the frame rate as 25 fps/30fps

3.2 DAY/NIGHT

ness of the IR LED. IR LED is selected as Smart, you can set the bright-EXT, you can set the IR LED as Smart and CDS. If the NIGHT switches. Under the mode of the AUTO and Color, B/W, AUTO and EXT are selectable for DAY/



Figure 3-2 DAY/NIGHT Figure 3-3 AWB

3.3.3 AWB

are selectable for AWB. Under the mode of AUTO, as User, You need to set the R/G/B Gain manually indoor/outdoor mode. If the AWB mode is select you need to set the R-G/B-G Gain and to select an Auto, User, Push, 8000k, 6000k, 4200k and 3000k

3.3.4 AE

of the image. **Brightness**: Brightness refers to the brightness You can set the AE mode as HOLD, DC and ESC.

1/60, 1/100, 1/120, 1/250, 1/500, 1/1k, 1/3k and You can set the shutter as AUTO, 1/25, 1/30, 1/50 **Shutter**: Shutter denotes the speed of the shutter

Flicker: You can set the flicker status as 50HZ/60HZ to prevent image flicking.

BLC gain from 0 to 16. brightness of the whole image. You can set the **BLC**: BLC bases on the back area to enhance the

AGC: AGC optimizes the clarity of image in poor light scene. The value of AGC can be set from 1-5 image gets darkened or blurred on the periphery **LSC**: LSC corrects the phenomenon where the

3.3.5 SPECIAL

4. RETURN	3. HLC	2. MOTION	1. PRIVACY	SPECIAL	
RET			ZONE	IAL	

Figure 3-4 SPECIAL

MASK PAT as OFF, GRAY, WHITE or BLACK. Set the SX/EX/SY/EY value to define the position and size Privacy zone: Select a PRIVACY area. Set the

> 0 second to 255 seconds. as ICON/TRANCE/OFF. Set the hold time from Motion: Set the Motion status as ON or OFF. Set the SENSITIVITY from 0 to 255. Set the alarm status

HLC: HLC supplements the brightness of the peripheral area of the image. You can set the mask value and threshold from 0 to 255.

3.3.6 EFFECT

8. RETURN	7. FLIP	6. MIRROR	5. BRIGHT OFF.	4. CONTRAST	3. SHARPNESS	2. COLOR HUE	1. COLOR GAIN	EFFECT
RET	9	ON	_	150	25	200	200	_

Figure 3-5 EFFECT

Color Gain: Color gain adjust this feature to change the saturation of the color. You can set the value

Color Hue: You can adjust the image HUE from

detail that an imaging system can reproduce. **Sharpness:** Sharpness determines the amount of You can set the value from 0 to 255

Contrast: Contrast enhances the difference in

Bright Off.: Bright Off. refers to the brightness color and light between parts of an image You can set the value from 0 to 255.

compensation of the image. You can set the bright Mirror: You can set the Mirror status as ON/OFF. compensation value as 0 or 1.

3.3.7 SYSTEM

Flip: You can set the FLIP status as ON/OFF.

O. REI OXIV	5. FACTORY INIT	4. LANGUAGE	NAME DISP.	2. ID DISP.	1. CAMERA ID	SYSTEM	
Ē	무 무	ENG	ON.	ON	255		

Figure 3-6 SYSTEM

Select the ID display and name display status as You can set the camera ID from 0 to 255.

of the menu Chinese and English are selectable for the language

setting the factory initialization status as ON You can restore the camera to the default by

3.3.8 EXIT

Exit and Save & exit are selectable.